

PABNA UNIVERSITY OF SCIENCE AND TECHNOLOGY



Faculty of Engineering & Technology
Department of Information and Communication Engineering

Lab report

Course name : Signal and systems

Course Code : ICE - 2204.

Experiment name: Extracting abnormalities from raw PPG signal.

Submitted By:

Siam Khan

Roll: 220620

Session: 2021-22

2nd Year 2nd Semester

Department of ICE,
PUST

Submitted To:

Dr. Md. Imran Hossain

Associate Professor

Department of Information and

Communication Engineering,

Pabna University of Science and

Technology, Pabna

Date of Submission: 14.02.2025

Theory:

1. Raw PPG Signal:

- A PPG signal is a reflection of blood volume changes in the microvascular bed of tissue, typically captured via optical sensors (like in a pulse oximeter).
- The signal is usually in the form of a time series of light intensity, which corresponds to the cyclic pumping of blood by the heart.

2. Preprocessing the Signal:

- **Filtering:** PPG signals often contain noise from movement, ambient light, or other sources. Filters like bandpass (0.5-5 Hz) or lowpass filters can remove these high-frequency artifacts.
- **Normalization:** The signal is typically normalized to a range to help reduce variability due to sensor differences.

3. Feature Extraction:

- From the filtered PPG signal, features such as **heart rate**, **heart rate variability (HRV)**, **pulse rate**, and **signal morphology** are extracted.
- **Peak Detection:** Peaks correspond to heartbeats. The intervals between these peaks can be analyzed to detect abnormal rhythms.

4. Anomaly Detection:

- **Heart Rate Analysis:** An abnormality is detected if the heart rate is significantly higher or lower than expected (e.g., tachycardia or bradycardia).
- **Frequency Domain Analysis:** By applying a Fourier transform, anomalies in the frequency spectrum, such as changes in the power of certain frequency bands, can indicate potential issues.
- **Machine Learning:** A classifier can be trained on labeled data to identify abnormal heart rhythms, e.g., arrhythmias.

5. Abnormality Detection Methods:

- **Statistical Methods:** Comparing features like average heart rate or HRV to thresholds.
- **Pattern Recognition:** Detecting unusual patterns in the waveform, such as premature beats or irregular rhythm.

Sorce code: Given Below

```
import numpy as np
import matplotlib.pyplot as plt
from scipy.signal import find_peaks, butter, filtfilt
def bandpass_filter(ppg_signal, lowcut=0.5, highcut=5.0, fs=100,
order=4):
    nyquist = 0.5 * fs
    low = lowcut / nyquist
    high = highcut / nyquist
    b, a = butter(order, [low, high], btype='band')
    filtered_signal = filtfilt(b, a, ppg_signal)
    return filtered_signal
def detect_peaks(ppg_signal, distance=50):
    peaks, _ = find_peaks(ppg_signal, distance=distance)
    return peaks
def calculate_heart_rate(peaks, fs):
```

```
# Compute the time intervals between successive peaks (in seconds)
```

```
peak_intervals = np.diff(peaks) / fs
```

```
# Calculate heart rate (beats per minute)
```

```
heart_rate = 60 / peak_intervals
```

```
return heart_rate
```

```
def detect_anomalies(heart_rate, threshold=100):
```

```
    abnormal_heart_rate = []
```

```
    for hr in heart_rate:
```

```
        if hr > threshold: # For simplicity, consider HR > 100 as an anomaly (tachycardia)
```

```
            abnormal_heart_rate.append(hr)
```

```
    return abnormal_heart_rate
```

```
# Sample PPG Signal (example data)
```

```
fs = 100 # Sampling frequency
```

```
time = np.linspace(0, 10, fs * 10) # 10 seconds of data
```

```
raw_ppg_signal = np.sin(2 * np.pi * 1 * time) + 0.2 *  
np.random.randn(len(time)) # Sine wave with noise
```

```
# Apply the bandpass filter
```

```
filtered_ppg_signal = bandpass_filter(raw_ppg_signal)
```

```
# Detect peaks (heartbeats)
```

```
peaks = detect_peaks(filtered_ppg_signal)
```

```
# Calculate heart rate from peaks
```

```
heart_rate = calculate_heart_rate(peaks, fs)
```

```
# Detect anomalies based on a threshold
```

```
abnormal_heart_rate = detect_anomalies(heart_rate)
```

```
# Plotting the results
```

```
plt.figure(figsize=(12, 6))
```

```
plt.subplot(2, 1, 1)
```

```
plt.plot(time, filtered_ppg_signal)
```

```
plt.plot(time[peaks], filtered_ppg_signal[peaks], 'ro')
```

```
plt.title('Filtered PPG Signal with Detected Peaks')
```

```
plt.subplot(2, 1, 2)
```

```
plt.plot(heart_rate)
```

```
plt.axhline(y=100, color='r', linestyle='--')
```

```
plt.title('Heart Rate (Detected Anomalies above 100 bpm)')
```

```
plt.show()
```

```
print(f'Abnormal Heart Rate Episodes: {abnormal_heart_rate}')
```

Output:

